Diagram for Connecting the Ricoh Digital Cameras to PC Computer

Serial Ports

NOTE: Your computer may not be configured exactly as the one shown.

Camera Cable

Attached the camera cable to an open 9-pin serial port or, if necessary, detach a 9-pin serial mouse and connect the camera in place of it. (See downloading instructions using Mousekeys or KeyBoard Shortcuts).

If you only have an open 25-pin serial port, most circumstances will allow the use of a 9 to 25 pin adapter on the camera cable. However, if this manner does not make reliable connection, then it is recommended that you use your mouse port.

Notes: If you have a serial mouse and a modem in your system, then you may have all the available IRQ's for serial transfers occupied. If this applies, you will need to connect the camera to your mouse port and follow the directions for using Mousekeys and/or keyboard shortcuts. These directions are available on our faxback system at 800-442-8796, document 1206 and document 1220.